

USER MANUAL



HDWIFICam Pro

This manual describes how to use this WIFI camera and install the supplied software. Be sure that you have read and understood its contents before using the camera.

To get started, you need:

1. A wireless network (only support 2.4G)
***Use numbers and letters in creating network name and password.**
2. A smart device, such as an Android Smart Phone or Tablet (Android version 6.0 or latest) or an iPhone, iPad, or iPod Touch (IOS version 8.0 or latest).

APP Download:



HDWIFICam Pro



QR Code

Download the App “HDWIFICam Pro” from Google Play Store (for Android) or Apple Store (for iOS). Or scan the QR code to download the APP.

Three ways to add and use camera

①

**IP mode setting
for new device**



②

**Add an Online
device (IP Mode)**



③

**AP mode setting
for new device**


***AP mode for point to point , the camera can not be view remotely . the phone need to be close to the camera to be able to view the live videos. **

Way ① IP Mode Setting


***Camera configured**

Before setting, connecting the device with power supply and turn it on.

Open the “HDWIFICam Pro” App , Click + to add a new device ,when using the camera for the first time please select the first way .



Go to “ Setting” on your device . Tap on “Wi-Fi” and connect the network same as camera’s UID (which is unique to each unit)



*****If there is no hotspot WIFI please reset the camera and wait the camera reboot*****

Android system ^

Internet may not be available


Connect to another network or turn on Switch to mobile data.

Switch to mobile data


Another network

*****If your Android system phone show you that “the current WLAN network cannot access the internet, Switch to another network?” Just ignore it.****

After connecting with the UID , you need select your home ' s 2.4Ghz WI-FI signal and enter the correct password . Confirm the password and connect. Then click “done “.




The camera will reboot. It takes about 2-5 minutes, then the camera will show online.



If the camera show “disconnected “,
click UID number to refresh the state .

***If the camera show “connection timeout”,
That means Wi-Fi password is wrong . Please
reset the camera ,and connect again.**

Live Video



The screenshot shows the HDWiFi Cam Pro app interface. At the top, the status bar displays the time 06:30 and various system icons. The app header includes a grid icon, a list icon, the text "HDWiFi Cam Pro", a search icon, and a plus icon. Below the header is a camera card for "Camera DGK140222GLUPB" with an "Online" status and a settings gear icon. The main area is a large, light blue live video feed. At the bottom, there is a navigation bar with four icons: Camera (selected), Photo, Video, and Event. To the right of the app is a sidebar menu with the following items:

- Multiple screen
- Large/Samll view
- LAN search
- Add device
- Device list
- Local images
- Local & SD card videos
- Alarm event
- Menu setting




-  Upside/Down
-  Left/Right
-  Indicator Light ON/OFF
-  Night Vision ON/OFF
-  Resolution Rate
-  Video Record
-  Snapshot
-  Voice intercom
-  Speaker
-  More

Way ② Add an online device

***Camera configured**


The camera must be already connected to a network (IP Mode).

Open the “HDWIFICam Pro” App , Click + to add a new online device



Input the UID number (you also can scan the camera QR Code to get the UID number), then input new password if changed. The default

password is 6666.




***If you forgot your new password , you could reset the device and set the IP Mode again.**

Way ③ AP mode setting


***Camera configured**

Before setting, connecting the device with power supply and turn it on.

Open the “HDWIFICam Pro” App , Click + to add a new camera .




Go to “ Setting” on your device . Tap on “Wi-Fi” and connect the network same as camera’s UID (which is unique to each unit)



***If there is no hotspot WIFI please reset the camera and wait the camera reboot**

After connecting the device ' s hotspot Wi-Fi , it will be added automatically . And you could view the live videos now .



If the camera show “disconnected “, click UID number to refresh the state .

***AP mode for point to point , the camera can not be view remotely . the phone need to be close to the camera (less than 10 meters) to be able to view the live videos**

FREQUENTLY ASKED QUESTIONS

[What Micro SD Card is required for recording? Why can't I use my Micro SD Card for recording?](#) The camera supports up to 128 GB Micro SD card. Please use High Speed Class 10 FAT formatted memory card. You must format the Micro SD before using. If SD card is not recognized when inserted into camera, just remove and re-insert.

[Why can't the camera go online?](#)

1. Powerless.
2. Check if your router is working properly or not.
3. Weak Wi-Fi signal.
4. Wrong password wrong while Wi-Fi setting

[Why is remote monitoring not smooth?](#) You should choose a suitable resolution to watch according to your internet speed.

[How could i save in SD card?](#) Open the setting menu to set the SD card video recording.

[Why i can't save to my SD card?](#) SD Card must be formatted if this is your first time to use it .

[How do I when I forgot my password?](#) Press reset key for 10 seconds and restore the factory setting.

Disclaimer:

Our company would not be responsible to any consequences cause by improper use, please use it in appoint environment and comply with the relevant laws and regulations!